

PARTS LIST (TYI-9025)

*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No, PART NO. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
01	HS05080BW-16	HEX. SOC. HD. BOLT+SW	4	51	11205101	PUSHER	1				
03	11100302	CAP	1	52	11205201	SLIDE BLOCK	1				
04	12100401	SEAL**	1	53	11305301	SPRING**	1				
05	12100501	SPRING**	1	54	11305401	ROD	1				
06	OR13824N	O RING**	1	56	11305601	SET BLOCK	1				
07	11100702	CAP SEAL**	1	57	HS04070B-08	HEX. SOC. HD. BOLT	2				
08A	12100801A	HEAD VALVE ASM.	1	58	11205801	END CORE	1				
11	OR31824N	O RING**	1	59	13908102	STOPPER	1				
13	OR22431N	O RING**	1	60	32906001	SPRING	1				
14A-1	11201402A	DRIVER ASSEMBLY**	1	61	12506802	SET PLATE	1				
14A-2	11201401A	DRIVER ASSEMBLY**	1	62	13908401	STEPPED PIN	1				
18	OR44431N	O RING**	1	63	HS04070B-10	HEX. SOC. HD. BOLT	2				
19	11101902	CYLINDER	1	64	HS05080B-16	HEX. SOC. HD. BOLT	1				
19-3	11101903	COLLAR	1	65	LN0500N	LOCK NUT	1				
20	11002001	BUMPER**	1	66	11106601	COVER	1				
21	OR28318N	O RING**	1	67	12106401	AIR PLUG	1				
23	11102307	BODY	1	68	OR40030N	O RING**	1				
24	OR01919N	O RING**	2	69	11306902	BRACKET	1				
25	12102501	JOINT GUIDE	1	71	US05080B-06	UM. HD. BOLT	1				
26	11002601	SPRING	1	72	FW050120B-10	FLAT WASHER	1				
27	11002702	GUIDE SAFETY LEVER	1	73	12103301	SEAL	1				
31	11303101	SAFETY LEVER	1	74	13907403	EXHAUST COVER	1				
32	11103201	STEPPED PIN	2	77	ER0250R	E RING	1				
33	11006903A	BUMP FIRE SWITCH ASSEMBLY	1	78	HS05080B-10	HEX. SOC. HD. BOLT	2				
40A	15104501A	TRIGGER ASSEMBLY	1								
41	HS04070B-06	HEX. SOC. HD. BOLT	2								
42	14804201	NOSE COVER	1								
43	HS04070B-12	HEX. SOC. HD. BOLT	2								
44	HS05080BW-20	HEX. SOC. HD. BOLT+SW	2								
46	11204601	NOSE	1								
47	11304701	SET PLATE	1								
48	12104501	SET PLATE	1								
49A	11304901A	STAPLE GUIDE UNIT	1								
50	11205004	MAGAZINE	1								